SIEMENS 3943



**Climatix**<sup>™</sup>

# Climatix Extension Modules ECV2

POL96U.00/XXX POL96E.00/XXX

ECV2 extension modules are products of Climatix range. They are designed for driving a broad range of EEV valves with bipolar or unipolar stepper motors. IOs of ECV2 extension modules can be configured for various applications of chiller and heat pump. The extension modules offer the following features:

- Power supply AC 24 V or DC 24 V
- 2 independent channels supporting bipolar \*) stepper motors (chopper drive)
- 12 universal IOs
- DC 24 V and DC 5 V power supplies on board for active sensors
- 4 relay outputs
- 2 Triac outputs: DO1, DO2 (AC 24...230 V)
- 1 digital input galvanically isolated for AC 115/230 V
- Peripheral bus interface for local/remote extension IOs
- LED indicator for stepper motor driver

POL96U.00/XXX has a UPS for driving the electronic valve to a safe position when power failure occurs.

\*) unipolar motors in bipolar-current mode only, full step (5, 6, 8-wires)

# Electronic expansion valve

Electronic expansion valves control refrigerant mass flow in evaporators in evaporators for chillers, air-conditioners and refrigerators applications. In addition modulating valves can be used for several control functions such as liquid injection, hot gas bypass and evaporator pressure regulation.


ECV2 extension modules are designed as an electronic expansion valves driver, featuring two independently channel drive bipolar stepper motors. With the main controller one ECV2 module independently can manage two electronic expansion valves. Each channel of ECV2 module controls refrigerant superheat and optimizes the efficiency of the refrigerant circuit, to enhance the maximum capacity for chillers, air-conditioners and refrigerators.

#### Bipolar stepper motors


Modulating refrigerant valves that are equipped with bipolar stepper motors are available for a wide capacity range.

Bipolar permanent magnet and hybrid motors have two windings. The drive circuitry for such a motor requires an *H-bridge* control circuit for each winding. Briefly, an H-bridge allows the polarity of the power applied to each end of each winding to be controlled independently.

#### Installation concept



# Communication concept



#### **Disposal**




The devices are considered electronics devices for disposal in term of European Directive 2012/19/EU and may not be disposed of as domestic waste.

- Dispose of the device via the channels provided for this purpose.
- Comply with all local and currently applicable laws and regulations.

#### **Technical data**

Power supply	Operating voltage	AC 24 V ± 20%; DC 24 V ± 10%		
	Frequency	4565 Hz		
	Max. AC-Current consumption	2.2 A, 41 W		
	Max. DC-Current consumption	1.9 A, 39 W		
	Connection	Peripheral Bus		
Power distribution	Max pass through current	3.15A @ AC 24V / 3.54A @ DC 24V		
General data	Dimensions in mm	180 x 110 x 75		
	Weight excl. packaging			
	POL96U.00/XXX	422.6g		
	POL96E.00/XXX	385.5g		
	Base	Plastic, pigeon-blue RAL 5014		
	Housing	Plastic, light-grey RAL 7035		
Universal IOs	Configurable	By software		
X1X12 (T1, T2, T3)	Reference potential	Terminals <sup>⊥</sup>		
,	Contact voltage	Max. DC 24 V (SELV)		
	Over voltage protection Max. 40 V			
	Analog inputs (X1X8) Ni1000			
	Sensor current	Max. 1.4 mA		
	Resolution	0.1 K		
	Accuracy in the range -50150 °C	0.8 K		
	Pt1000			
	Sensor current	Max. 1.8 mA		
	Resolution	0.1 K		
	Accuracy in the range -40120 °C	0.9 K		
	02.5 kΩ			
	Sensor current	Max. 1.8 mA		
	Resolution	1 Ω		
	Accuracy	5 Ω		
	DC 05 V input for ratiometric sensors			
	Resolution	1 mV		
	Accuracy at 0 V	10 mV		
	Accuracy at 5 V	30 mV		
	Input resistance	100 kΩ		







Connecting a ratiometric sensor to universal IOs Connecting NTC to universal IO




Max. 140 µA







NTC 100k ( $\mathbf{B}_{25/85} = 3977 \text{ K}$ ) Sensor current

Max. 140 μA







# Analog inputs (X9...X10)

Ni1000


Sensor current Max. 1.4 mA
Resolution 0.3 K
Accuracy in the range -50...150 °C 0.7 K


Pt1000

Sensor current Max. 1.8 mA
Resolution 0.3 K
Accuracy in the range -40...120 °C 1.0 K

NTC 10k ( $B_{25/85} = 3977 K$ )

Sensor current Max. 500 µA





#### Note



These data are acquired under operating temperature of 25 °C.


Analog inputs (X1X8)	
DC 010 V input	
Resolution	1 mV
Accuracy at 0 V	10 mV
Accuracy at 5 V	30 mV
Accuracy at 10 V	50 mV
Input resistance	100 kΩ
DC 0/420 mA input	
Resolution	1 μΑ
Accuracy at 4 mA	40 uA
Accuracy at 12 mA	80 uA
Accuracy at 20 mA	120 uA
Impedance of DC 0/420 mA	Typ. 450 Ω

#### Analog inputs (X11...X12) DC 0...10 V input Resolution 11 mV 45 mV Accuracy at 0 V Accuracy at 5 V 60 mV Accuracy at 10 V 80 mV Input resistance $100 \text{ k}\Omega$ DC 0/4...20 mA input Resolution 21 µA Accuracy at 4 mA 85 uA 100 uA Accuracy at 12 mA Accuracy at 20 mA 120 uA Impedance of DC 0/4...20 mA Typ. 500 Ω

Note



These data are acquired under operating temperature of 25 °C.



Voltage input DC 0...10 \
Current input 4...20 mA

#### Digital inputs (X1...X8)

0/1 digital signal (binary)

Sampling voltage / current

Contact resistance

Delay

Pulse frequency

For potential-free contacts


DC 24 V / 8 mA

Max. 200 Ω (closed)

Min. 50 k $\Omega$  (open)

10 ms

Max.20 Hz



Connecting floating contacts to universal IOs

# Analog output (X1...X4)

DC 0...10 V output


Resolution 11 mV
Accuracy at 0 V 66 mV
Accuracy at 5 V 95 mV
Accuracy at 10 V 124 mV

Output current 1 mA (short-circuit-proof)

DC 4...20 mA output

Resolution22 μAAccuracy at 4 mA220 μAAccuracy at 12 mA196 μAAccuracy at 20 mA243 μA

**Note** These data are acquired under operating temperature of 25 °C.



Connecting voltage output and current output to universal IOs

## Analog / digital outputs (X5...X8)


DC 0...10 V output

Resolution 11 mV
Accuracy at 0 V 66 mV
Accuracy at 5 V 95 mV
Accuracy at 10 V 124 mV

Output current 1 mA (short-circuit-proof)

DC output for off board loads

Switching voltage DC 24 V Switching capacity Max. 25 mA



Connecting voltage output and offboard relays to universal IOs

# Powering sensors Active / ratiometric 5 V, 24 V (T2, T3)

### 3 x 2 outputs

Voltage / current

Voltage / current Reference potential

Connection


DC 5 V: 3x20 mA / ±2.5%<sup>1)</sup>

DC 24 V: 3x40 mA, -25% to +10% accuracy<sup>2)</sup>

Terminals <sup>⊥</sup>

Short-circuit-proof





Pressure transmitter

(6 x 25 F at 2.21 V)

Connecting a ratiometric sensor AC 24 V sensor supply voltage

#### **Motor driver**

### M1+...COM (T7, T8)

# Driver for bipolar stepper motor

Constant-current mode Short-circuit-proof
Switching frequency 50 kHz (variable)
Full-step mode 4 steps per revolution

Programmable current 0.1...0.5 A<sup>1)</sup>
Programmable hold current 0.0....0.5 A
Motor voltage Max. 42 V

Programmable speed Max. 500 steps per s
Programmable traverse path 0....30,000 steps
Programmable overdrive 0...2,500 steps
Programmable reference point Zero or max. point

Max. output power for each motor 10 W
Length of motor cable <10 m

## **UPS (POL96U.00)**


Energy storage Ultracaps

Usable energy >187 Ws
Charging time <3 min

<sup>1)</sup> avoid pulsating current

<sup>&</sup>lt;sup>2)</sup> max. capacitive load 100µF

<sup>1)</sup> from VVS11 0.05...0.6 A



Note

For dedicated valve parameters, approved by valve manufacturers please contact your local Siemens representative.

Examples of approved valves parameters are listed on page 17

**Relay outputs** Q1...Q4 (T4)

Relay: type, contact

Monostable, NO contact

Contact rating

Switching voltage

AC 24 V...230 V

Nominal current (res. / ind.) Switching current at AC 19 V Max. AC 3 A/2 A (cosφ 0.6)


Min. AC 30 mA




Warning

Do not mix SELV / **PELV** and line voltage on the same terminal.

Use external protection for inductive load.





Connecting indicator lamps to relay outputs

**Triac outputs** 

DO1, DO2 (T5)

Triac output values

Switching voltage AC 24 V...230 V Max. 0.5 A Switching capacity Min. current 10 mA

Max. external supply line fusing 2.0 A slow wire fuse or circuit breaker

-<u>↑</u> 24...230 V ~


D01



Warning

Do not mix SELV / **PELV** and line voltage on the same terminal.

Use external protection for inductive load.



Connecting solenoid valves to Triac output

# Digital input AC 230 V

DL1 (T6)


0/1 digital signal (binary)

Galvanically isolated contact

Nominal voltage AC 115 V...AC 230 V Frequency range 45...65 Hz

Sample current 3 mA @ AC 230 V

Delay 100 ms
Pulse frequency Max. 5 Hz



Connecting a AC 230 V signal to a galvanically isolated digital input

_			_		
(:0)	nne	CTIO	n te	rmin	าลเจ

Possible plugs for IO signals	Phoenix FKCVW 2,5 / x-ST
(not included)	Phoenix FKCT 2,5 / x-ST
	Phoenix MVSTBW 2,5 / x-ST

Solid wire 0.5...2.5 mm<sup>2</sup> Stranded wire (twisted and with ferrule) 0.5...1.5 mm<sup>2</sup>

Cable lengths In compliance with load, local regulations

and installation documents

Max. 10,000 m above sea level

#### Peripheral bus

Power supply	Ueff = AC 24 V $\pm$ 20%, fmain = 4565 Hz
	or U = DC 24 V $\pm$ 10%, no internal fuse

Bus termination 120  $\Omega$  +1 nF

Board-to-board (not included) ZEC 1,0 / 4-LPV-3,5 GY35AUC2CI1 Board-to-wire (not included) ZEC 1,0 / 4-ST-3,5 GY35AUC1R1,4

Stranded wire (twisted and with ferrule) 0.2...1.0 mm²
Cable lengths Max. 30 m
Addressing DIP switches 1...5
Termination DIP switch 6

# Environmental conditions

Operation	3K5 according IEC 721-3-3
Temperature	-4070 °C (POL96E.00)
	-4060 °C (POL96U.00)

Relative humidity 5%....95% (non-condensing)

Absolute humidity 1...29 g/m<sup>3</sup>

Atmospheric pressure Min. 700 hPa, corresponding to Max. 3,000 m above sea level

Transport IEC 60721-3-2
Temperature -40...70 °C

Humidity <95% r.h. (non-condensing)
Atmospheric pressure Min. 260 hPa, corresponding to

#### **Protection**

**Standards** 

Degree of protection	IP20 (EN 60529)
Pollution degree	2
Safety class	Suitable for use in plants with safety class II
EU Conformity (CE)	CB1T3434xx *)
RCM Conformity	CB1T3434en_C1 *)
Listings	

UL916, UL873 CSA C22.2M205

#### **BSP LEDs**

The status of the BSP LED is defined as below:

Mode	LED
BSP upgrade mode in progress	Per second flashing between red and green.
Application not loaded	Orange flashing with 50ms on and 1000ms off
Application loaded but not running or BSP Upgrade mode active	Orange
Application running	Green
BSP error (software error)	Red flashing with 2Hz
Hardware error	Red
Fail safe mode (in case that the BSP upgrade was interrupted)	Orange with Red flashing every second for 500ms

#### **BUS LEDs**

This LED indicates the status of the communication with the controller.

Mode	LED
Communication running but parameter from the application wrong or missing, or the calibration from the factory not correct	Orange
Communication running, IO working	Green
Communication down	Red

#### Note



POL96X.00/XXX is a programmable extension module (for programming instruction of local application see Sapro Online-Help).

In case that a failsafe drive is performed (driver connected and referenced), all outputs and LEDs are switched off during the fail safe drive! If the position is reached and the internal super capacitor has still power, the internal application starts again and can control the outputs (therefore BSP LED green).

<sup>\*)</sup> The documents can be downloaded from <a href="http://siemens.com/bt/download">http://siemens.com/bt/download</a>.

# ECV closing and opening LEDs

In addition to the standard LED, the stepper has two LEDs for each motor which show the status of the motor.

Status	Open LED	Close LED
Motor not moving in this direction	OFF	OFF
Valve is moving to the fail safe position in case of power fail (only for UPS versions)	OFF	OFF
Motor full open if referenced	ON	OFF
Valve is closing	OFF	Green flashing 250 ms ON 250 ms Off
Valve is opening	Green flashing 250 ms ON / 250 ms OFF	OFF
Valve is moving to the fail safe position closed	OFF	Green short flashing 50 ms ON / 450 ms OFF
Valve is moving to the fail safe position open	Green short flashing 50 ms ON / 450 ms OFF	OFF
Stepper error (for example, the diagnostics detected an error at startup, such as not connected or shortened coil)	Green short flashing 50 ms ON // 450 ms OFF	Green short flashing 50 ms ON / 450 ms OFF


#### Note



Firmware of POL96X.00/XXX features different diagnostic functions such as disconnection detection, under voltage detection or shorted coil. The function "disconnection detection" is active only during valve / motor positioning, but not during hold on.

#### **DIP** switches

The extension module is equipped with DIP switches for communication with the controller. Switches 1, 2, 3, 4, and 5 are configurable to set the slave address, while switch 6 acts as peripheral bus termination. When the extension module operates as the termination in the network, switch 6 must be set to ON.



The order of bits for the switch is from 5 to 1, 5 is the lowest bit while 1 is the highest bit. The following table shows the logic of slave address:

Switch 1	24
Switch 2	$2^3$
Switch 3	$2^2$
Switch 4	2 <sup>1</sup>
Switch 5	2 <sup>0</sup>

By combining switches 1, 2, 3, 4 or 5, maximum 31 slave addresses can be configured. The configuration formula is as follows:  $2^4+2^3+2^2+2^1+2^0=31$ . Below are some configuration examples:

DIP Switch configuration of Extension Module							
No.	Schematics	No.	Schematics	No.	Switch 5	No.	Schematics
1	ON DIP 1 2 3 4 5 6	9	ON DIP 1 2 3 4 5 6	17	ON DIP 1 2 3 4 5 6	25	ON DIP 1 2 3 4 5 6
2	ON DIP 1 2 3 4 5 6	10	ON DIP 1 2 3 4 5 6	18	ON DIP 1 2 3 4 5 6	26	ON DIP 1 2 3 4 5 6
3	ON DIP 1 2 3 4 5 6	11	ON DIP 1 2 3 4 5 6	19	ON DIP 1 2 3 4 5 6	27	ON DIP 1 2 3 4 5 6
4	ON DIP 1 2 3 4 5 6	12	ON DIP 1 2 3 4 5 6	20	ON DIP 1 2 3 4 5 6	28	ON DIP 1 2 3 4 5 6
5	ON DIP 1 2 3 4 5 6	13	ON DIP 1 2 3 4 5 6	21	ON DIP 1 2 3 4 5 6	29	ON DIP 1 2 3 4 5 6
6	ON DIP 1 2 3 4 5 6	14	ON DIP 1 2 3 4 5 6	22	ON DIP 1 2 3 4 5 6	30	ON DIP 1 2 3 4 5 6
7	ON DIP 1 2 3 4 5 6	15	ON DIP 1 2 3 4 5 6	23	ON DIP 1 2 3 4 5 6	31	ON DIP 1 2 3 4 5 6
8	ON DIP 1 2 3 4 5 6	16	ON DIP 1 2 3 4 5 6	24	ON DIP 1 2 3 4 5 6		

Note



The same address of extension module must be set in the application program of the controller. Zero cannot be set as the slave address.

Order data	Extension module 21 IOs	POL96E.00/STD	
		POL96U.00/STD	
Accessory parts	Plug set (screw type, side entry)	POL096.E5/STD	
	1 x Phoenix MVSTBW 2,5/2-ST GY7035		
	1 x Phoenix MVSTBW 2,5/3-ST KMGY		
	2 x Phoenix MVSTBW 2,5/5-ST GY7035		
	1 x Phoenix MVSTBW 2,5/7-ST GY7035		
	3 x Phoenix MVSTBW 2,5/8-ST GY7035		
	1 x Phoenix ZEC 1,0/4-LPV-3,5 GY35AUC2CI1		
	Plug set (spring cage, cable top entry) FKCT	POL096.E6/STD	
	Board-to-wire connector	POL002.43/STD	
	2 x Phoenix ZEC 1,0 / 4-ST-3,5 GY35AUC1R1,4	50 pcs	


## **Engineering notes**





Warning

To ensure protection against accidental contact with relay connections carrying voltages above 42  $V_{\rm eff}$ , the module must be installed in an enclosure (preferably a control panel). It must be impossible to open the enclosure without the aid of a key or tool.

AC 230 V cables must be double-insulated against safety extra low-voltage (SELV) cables.







Manufacturer	Unit /	Danfoss
	Dimension	
Valve Type		ETS 12.5, 25, 50, 100, 250, 400 *
CurrentSetpoint	[mA]	120
Speed	[Steps/s]	300
OverdriveOpen	[Steps]	0
OverdriveClose	[Steps]	300
HoldCurrentSetpoint	[mA]	0
DeadTimeSync	[Min.]	60
DelayDirection	[ms]	200
Step Mode		Full Step

<sup>\* (</sup>SKUs 034G0000-034G4999)

Maximum cable length 8 m. If a longer cable length is used, communication inductors such as the Danfoss AKA211 should be used.

Manufacturer	Unit / Dimension	Sporlan		
Valve Type		SER AA, A,	SERIF, G, J,	<b>SEHI</b> P, 175,
		B, C, D	K, L	400, T
CurrentSetpoint	[mA]	120	140	160
Speed	[Steps/s]	200, 400	240	200, 400
DelayDirection	[ms]	200		
OverdriveOpen	[Steps]	0		
OverdriveClose	[Steps]	300		
HoldCurrentSetpoint	[mA]	0		
DeadTimeSync	[Min.]	480		
TraversePath	[Steps]	2500	2500	6386
Step Mode		Full Step		

Sporlan EEVs are designed for long life and durability. Reinitializing the EEV (overdriving to zero position) more than three times per day is not needed.

Published by:
Siemens Switzerland Ltd.
Building Technologies Division
International Headquarters
Gubelstrasse 22
6301 Zug
Switzerland
Tel. +41 41-724 24 24
www.siemens.com/buildingtechnologies

© Siemens Switzerland Ltd 2012 Delivery and technical specifications subject to change

18 / 18